

T8 Instant Start

Electronic Ballast

T8 Instant Start – Dedicated Voltage



Also Operates: FBO32, F025, FBO24, F017, FBO16, F030/SS, FBO30/SS, (30W Lamps) & F028/SS (28W Lamps)

<20% THD Electronic T8 Fluorescent Ballasts

Primary Lamp Type	Number of Lamps	Voltage	Satco Order No.	Ballast Number	Case
F32T8	1	120	S6623	QT1X32T8120/ISN/SC	10
F32T8	1	277	S6633	QT1X32T8277/ISN/SC	10
F32T8	2	120	S6624	QT2X32T8120/ISN/SC	10
F32T8	2	277	S6634	QT2X32T8277/ISN/SC	10
F32T8	3	120	S6625	QT3X32T8120/ISN/SC	10
F32T8	3	277	S6635	QT3X32T8277/ISN/SC	10
F32T8	4	120	S6626	QT4X32T8120/ISN/SC	10
F32T8	4	277	S6636	QT4X32T8277/ISN/SC	10
Also operates F17T8 • F25T8 • F28T8/SS • F30T8/SS • F40T8 • FBO16 • FBO24 • FBO31 • FBO 32 For F40T8 operation, use 2 lamp ballast for 1 lamp, 3 lamp ballast for 2 lamps, 4 lamp ballast for 3 lamps.					
F96T8	1/2	120	S5211	QT2X59120/IS	10
F96T8	1/2	277	S5212	QT2X59277/IS	10

T8 Instant Start – Universal Voltage



Also Operates: FBO32, FBO31, F025, FBO24, F017, FBO16, F030/SS, FBO30/SS (30W Lamps) & F028/SS (28W Lamps)

<10% THD Electronic T8 Fluorescent Ballasts

Primary Lamp Type	Number of Lamps	Voltage	Satco Order No.	Ballast Number	Case
F32T8	1	120/277	S5207	QTP1X32T8/UNV/ISN/SC	10
F32T8	2	120/277	S5208	QTP2X32T8/UNV/ISN/SC	10
F32T8	3	120/277	S5209	QTP3X32T8/UNV/ISN/SC	10
F32T8	4	120/277	S5210	QTP4X32T8/UNV/ISN/SC	10
Also operates F17T8 • F25T8 • F28T8/SS • F30T8/SS • F40T8 • FBO16 • FBO24 • FBO31 • FBO32 For F40T8 operation, use 2 lamp ballast for 1 lamp, 3 lamp ballast for 2 lamps, 4 lamp ballast for 3 lamps.					
F96T8	2	120/277	S5213	QTP2X59T8/UNV/ISN/SC	10

T8 4 Foot Programmed Start Universal Voltage



Also Operates: F096T8/SS (55W Lamp)

< 10% THD Electronic T8 Fluorescent Ballasts

Primary Lamp Type	Number of Lamps	Voltage	Satco Order No.	Ballast Number	Case
F32T8	1	120/277	S5286	QTP1X32T8/UNV/PSNTC	10
F32T8	2	120/277	S5287	QTP2X32T8/UNV/PSNTC	10
F32T8	3	120/277	S5288	QTP3X32T8/UNV/PSNTC	10
F32T8	4	120/277	S5289	QTP4X32T8/UNV/PSNTC	10
Also operates F17T8 • F25T8 • F28T8/SS • F30T8/SS • FBO16 • FBO24 • FBO31 • FBO32					

Electronic Ballasts



T5 Programmed Start Universal Voltage

T5 Programmed Start

Primary Lamp Type	Number of Lamps	Voltage	Satco Order No.	Ballast Number	Case
F28T5	1	120/277	S5221	QTP1X28UNVPSNNL	20
F28T5	2	120/277	S5222	QTP2X28UNVPSNNL	20

Also operates F14T5 • F21T5 • F35T5



T5 HO Programmed Start

Primary Lamp Type	Number of Lamps	Voltage	Satco Order No.	Ballast Number	Case
F39T5/HO	1	120/277	S5214	QTP1X39/24T5HOUNVPSNNL	20
F39T5/HO	2	120/277	S5215	QTP2X39/24T5HOUNVPSNNL	20
Also operates F24T5/HO • FPC22 • FPC40 • FT24DL • CF24DF • FT36DL • CF36DF					
F54T5/HO	1	120/277	S5218	QTP1X54T5HOUNVPSNNL	20
F54T5/HO	2	120/277	S5219	QTP2X54T5HOUNVPSNNL	20
Also operates FT55DL • FPC55					
F80T5/HO	1	120/277	S5220	QTP1X80T5HOUNVPSNNL	20
Also operates FT80DL					



40 T12 Rapid Start

T12 F40T12 Rapid Start

Primary Lamp Type	Number of Lamps	Voltage	Satco Order No.	Ballast Number	Case
F40T12	1	120	S5258	QTP1X40T12/120/RSN/B	20
F40T12	1	277	S5259	QTP1X40T12/277/RSN/B	20
F40T12	2	120	S5260	QTP2X40T12/120/RSN/B	20
F40T12	2	277	S5261	QTP2X40T12/277/RSN/B	20
F40T12	3	120	S5262	QTP3X40T12/120/RSN/B	20
F40T12	3	277	S5263	QTP3X40T12/277/RSN/B	20



Electronic Ballasts

TT5 Instant Start



TT5 FT40DL Instant Start

Primary Lamp Type	Number of Lamps	Voltage	Satco Order No.	Ballast Number	Case
FT40	1	120	S5240	QT1x40/120/DL	10
FT40	1	277	S5241	QT1x40/277/DL	10
FT40	2	120	S5242	QT2x40/120/DL	10
FT40	2	277	S5243	QT2x40/277/DL	10
FT40	3	120	S5244	QT3x40/120/DL	10
FT40	3	277	S5245	QT3x40/277/DL	10

Compact Fluorescent



Primary Lamp Type	Number of Lamps	Voltage	Satco Order No.	Ballast Number	Case
CF13	1/2	120/277	S5223	OTP1/2X13CF/UNV/BS	20
CF13	1/2	120/277	S5225	OTP1/2X13CF/UNV/TS	20
Operates 1 or 2 each CF13DT/E • CF13DD/E					
CF18	1/2	120/277	S5226	OTP1/2X18CF/UNV/BS	20
CF18	1/2	120/277	S5228	OTP1/2X18CF/UNV/TS	20
Operates 1 or 2 each CF18DT/E • CF18DD/E					
CF26	1/2	120/277	S5229	OTP1/2X26CF/UNIV/BS	20
CF26	1/2	120/277	S5231	OTP1/2X26CF/UNIV/TS	20
Operates 1 or 2 each CF26DT/E • CF26DD/E Operates 1 each CF32DT/E • CF42DT/E					
CF26	1/2	120/277	S5232	OTP1/2XCF/UNV/BM	20
CF26	1/2	120/277	S5233	OTP1/2XCF/UNV/PM	18
CF26	1/2	120/277	S5234	OTP1/2XCF/UNV/TM	18
Operates 1 or 2 each CF26DT/E • CF26DD/E Operates 1 each CF32DT/E • CF42DT/E					
CF26	2	120/277	S5235	OTP2X26/32/42CF/UNIV/BM	20
CF26	2	120/277	S5236	OTP2X26/32/42CF/UNIV/PM	18
CF26	2	120/277	S5237	OTP2X26/32/42CF/UNIV/TM	18
Operates 2 each CF26DT/E • CF32DT/E • CF42DT/E					
CF57	1	120/277	S5238	OTP1X57CF/UNV/BM	20
CF57	1	120/277	S5239	OTP1X57CF/UNV/PM	18
Operates 1 each CF57DT/E • CF70DT/E					

BS = Bottom Mount / Plastic Case
 TS = Top Mount / Plastic Case
 BM = Bottom Mount / Metal Case
 PM = PEM Stud Mount / Metal Case
 TM = Top Mount / Metal Case

T2 Universal Voltage



T2 Subminiature

Primary Lamp Type	Number of Lamps	Voltage	Satco Order No.	Ballast Number	Case
FM13	1/2	120/277	S5246	QT-FM	50
Operates 1 or 2 FM6 • FM8 • FM11 • FM13					

Magnetic Ballasts

Rapid Start

F40T12 & F34T12 Rapid Start

Primary Lamp Type	Number of Lamps	Voltage	Satco Order No.	Ballast Number	Case
F34T12	1	120	S5274	MB1X40/120RS	10
F34T12	1	277	S5275	MB1X40/277RS	10
Also operates F40T12 • F40T10 • FB40T12 • FB34T12/SS • F30T12 • F25T12/SS					
F34T12	2	120	S6620	MB2X40/120RS	10
F34T12	2	277	S6622	MB2X40/277RS	10
Also operates F40T12 • F40T10 • FB40T12 • FB34T12/SS					
F40T12	1	120	S5276	MB1X40/120RES	16
Operates F40T12 FULL WATTAGE LAMPS ONLY - Not for use for F34T12 lamps					
F30T12	2	120	S5171	MB2X30/120RS	10
F30T12	2	277	S5170	MB2X30/277RS	10
Operates F30T12 and F25T12/SS Lamps					



Instant Start Slimline

T12 Slimline Instant Start

Primary Lamp Type	Number of Lamps	Voltage	Satco Order No.	Ballast Number	Case
F48T12	2	120	S5277	MB2X48/120IS	6
F48T12	2	277	S5278	MB2X48/277IS	6
Also operates F48T12/SS					
F96T12	1	120	S5279	MB1X96/120IS	6
F96T12	1	277	S5280	MB1X96/277IS	6
F96T12	2	120	S6621	MB2X96/120IS	6
F96T12	2	277	S5281	MB2X96/277IS	6
Also operates F60T12 • F64T12 • F72T12 • F84T12 • F96T12/SS					



Preheat/Trigger Start

T8 / T12 PreHeat and Trigger Start

Primary Lamp Type	Number of Lamps	Voltage	Satco Order No.	Ballast Number	Case
F15T12	1	120	S5268	MB1X15/120PH/TP	16
F20T12	1	120	S5269	MB1X20/120PH/TP	40
F20T12	1	120	S5270	MB1X20/120PH	40
F20T12	2	120	S5271	MB2X20/120PH/TP	16
Also operates F14T8 • F14T12 • F15T8 • F15T12					

TP = Thermal Protection



Magnetic

Ballasts

Circline



T9 Circline Rapid Start

Primary Lamp Type	Number of Lamps	Voltage	Satco Order No.	Ballast Number	Case
FC8T9	1	120	S5273	MB1X22/120CIRC	16
FC12T9	1	120	S5272	MB1X32/120CIRC	16

Also operates FC16T9

Rapid Start HO



T12 HO Rapid Start

Primary Lamp Type	Number of Lamps	Voltage	Satco Order No.	Ballast Number	Case
F96T12/HO	1	120	S5282	MB1X96HO/120RS	4
F96T12/HO	1	277	S5283	MB1X96HO/277RS	4
F96T12/HO	2	120	S5284	MB2X96HO/120RS	4
F96T12/HO	2	277	S5285	MB2X96HO/277RS	4

Also operates F24HO • F36HO • F42HO • F48HO • F60HO • F72HO • F84HO • F96HO/SS

Rapid Start VHO



T12 VHO Rapid Start

Primary Lamp Type	Number of Lamps	Voltage	Satco Order No.	Ballast Number	Case
F96T12/VHO	1	120	S5264	MB1X96/VHO/120RS	4
F96T12/VHO	1	277	S5265	MB1X96/VHO/277RS	4

Also operates F48/VHO • F60/VHO • F72/VHO • F96/VHO/SS

F96T12/VHO	2	120	S5266	MB2X96/VHO/120RS	4
F96T12/VHO	2	277	S5267	MB2X96/VHO/277RS	4

Also operates F72/VHO • F96/VHO/SS

Socket Ballasts Twist-Lock



Socket Ballasts

- Finish: Ivory
- Rating: 120V/60HZ
- CUL Listed
- Rated: Indoor / Outdoor
Minus 20 Degrees
- Replaceable
- Detachable:
Twist Lock Socket



13/18/26W
Standard



13/18/26W Uno Ring
Standard with Uno Ring

80-1325 13W
80-1324 18W
80-1383 26W

80-1335 13W
80-1336 18W
80-1382 26W



26/32/42W
Multi-Wattage



26/32W/Dimming
Multi-Wattage



13/18/26W
Low Profile

80-1323

80-1331
• Integral Harp Saddle
• Integral Dimmer
• Indoor Only

80-1384 13W
80-1385 18W
80-1386 26W

Primary Lamp Type	Satco OrderNo.	Finish	Terminal	Cap	Hickey	Wire	Pkd
13W	80/1325	Ivory	With 24" Leads	Cap	Hickey	UL1015	200
18W	80/1324	Ivory	With 24" Leads	Cap	Hickey	UL1015	200
26W	80/1383	Ivory	With 24" Leads	Cap	Hickey	UL1015	200
13W Uno / Ring	80/1335	Ivory	With 24" Leads	Cap	Hickey	UL1015	200
18W Uno / Ring	80/1336	Ivory	With 24" Leads	Cap	Hickey	UL1015	200
26W Uno / Ring	80/1382	Ivory	With 24" Leads	Cap	Hickey	UL1015	200
26/32/42 W	80/1323	Ivory	With 24" Leads	Cap	Hickey	UL1015	200
26/32 Dimmer	80/1331	Ivory	With 36" Leads	Cap	Hickey	UL1015	200
13W Small	80/1384	Ivory	With 24" Leads	Cap	Hickey	UL1015	200
18W Small	80/1385	Ivory	With 24" Leads	Cap	Hickey	UL1015	200
26W Small	80/1386	Ivory	With 24" Leads	Cap	Hickey	UL1015	200

SATCO BULB CHANGERS

The easy way to change hard to reach bulbs. Available in PAR, incandescent and R type changers.

Not Shown
Actual Size



Par Type
Bulb Changer
S70-3001



Incandescent
Bulb Changer
S70-0101



R Type
Bulb Changer
S70-3002



8-24 Ft. ▶

Alumiglass Extension Pole

S70-6624

Two section handle,
threaded end fits
all changers.
Professional quality.

8-16 Ft. ▶

Alumiglass Extension Pole

S70-6516

Two section handle,
threaded end fits
all changers.
Professional quality.

Note: For standard
ceilings, broomstick
handle will fit changers.



◀ 6-12 Ft.

Aluminum Extension Pole

S70-9272

Two section handle,
"nylon" threaded,
fits all changers.
Homeowner quality.



90-1310

Brass Finish
Light Bulb Cage
(for use with 90-445
keyless receptacle)



92-324

Medium to Medium
Porcelain
Extender
Overall Ext. 1"



92-323

Medium to Medium
Bakelight
Extender
Overall Ext. 1"